

PARTS LIST					P1/5
MODEL NO. EB330DSC					
NO	DESCRIPTION	BOM	SPEC	QTY	
1	CAP Screw	XCCMWS1025	M10x25	1	
2	Washer	27002	40x40.2x5	2	
3	Shaft	27003		1	
4	Anchor Block	27004		1	
5	C- ring		C扣25	1	
5*1	CAP Screw	XCCMWS61035	CAP M10x35	4	
5*2	CAP Screw	XCCMWS1025	CAP M10x25	5	
6	Bearing	QX6205	6205	2	
7	Left Body frame	28507		1	
7-1	PIPE connect	21007G*1		1	
7-2	PIPE connect for Body frame	30007*2	50x100x730	1	
7-3	Right Body frame	30007*3		1	
10	Knob	27010		2	
11	Blade Tension Handle	27011		1	
12	Big Waswher	QX51203	51203	1	
13	Lead Screw	27013*3	16*240mm	1	
13-1	tention gauge	UX1V		1	
13-2	Washer	XCWMWQC16311		1	
14	Hex. Socket Head Screw	XCCMWS6825	M8X25L	6	
15	Fixed Block	27015		2	
16	CAP Screw	XCCMWS6840	M8x40	4	
17	Bushing	27031B	20x25 内:12	1	
18	Reducer Block	30018		1	
19	Washer	Spring washer M8	M8	4	
20	Screw	XCM6F825	M8x25	4	
20*1	nut	XCM6A8	M8	4	
21	Reducer	30021		1	
22	Motor	27022/ZU005/ZE011		1	
25	CAP Screw	XCCMFS61025	M10x25	1	
27	Key	2J037	8x7x70	1	
28	Output Shaft	30028		1	
29	Key	2J021	7x7x30	1	
30	Bearing	27030	6906	2	
31	Spring Support	30031		1	
31*1	spring holder screw	27031A*1		1	
32	Spring	32147		1	
33	Steel Brush	30033,27033*2,*3,*4(1)-(3)		1	
33*1	Blade Cover	30033*1		1	
33*2	Brush holder	30033*2		1	
34	Screw		M16x40	1	
34*1	Bearing Cover	75081		1	
35	Spring Washer	32042(1)		2	
36	Frame Pivot Shaft	30036		1	
38	Screw			2	
39	Screw		8*25	1	
39-1	copper	12060C		1	
40	Fixed Block	32091		1	

PARTS LIST

P2/5

MODEL NO. EB330DSC

NO	DESCRIPTION	BOM	SPEC	QTY
41	Set Screw	XCCMJS688	M8x8	2
42	Switch	51021	VMN-15S	1
43	Handel	27043		1
44	Handel Pipe	285044		1
45	Screw		M6x20	1
47	Screw	XCM6F835	M8x35	2
48	Blade adjust stick	30048		1
50	Screw	XCMJ510	M5x10	2
52	Blade Cover (Front)	27052 #7037		1
53	Blade Adjust (Front)	30053		1
54	Guide	32084		2
55	Guide holder	32078		4
55-1	Guide	32079		4
56	Screw			4
60	Eccentric Guide	27057		4
61	Bearing	QX608(1)	608	8
62	Screw	XCM6F515	5x15	4
63	CAPSCREW	XCCMWS6840	M8x40	8
64	Spring Washer	XCWMWCC8	M8	1
65	Blade Adjustable (Rear)	30065		1
65-1	Valve	21049G*1		2
66	CAPSCREW			1
67	Chip Plate	30067#7037		1
68	Screw			2
69	Spring Washer	XCWMWCC5		1
70	Screw	XCM6F510	M5	1
71	Drive Wheel	30071		1
72	Washer	27002	40x10.2x5	1
73	Screw	XCCM1S61025		1
74	CAPSCREW			1
74-1	Washer			2
74-2	Nut			2
74-3	Cover Switch			1
75	Blade Back Cover	30075 #7035		1
75-1	Blade Left Cover	30075*1#7037		1
75-2	Blade up cover	30075*2#7037		1
75-3	Blade down cover	30075*3#7035		1
76	Wire fixed Board	30076		1
76-1	CAPSCREW	XCCMWS6816		2
78	Saw Blade	30078	2965x27x0.9	1
79	Idler Wheel	30079		1
80	C-ring	XCWMDCS25	S-25	1
81	Screw	XCM6F820	M8x20	1
82	Washer	XCMM8233	M8 X23X3	1
83	Wheel	15075		1
84	Bearing Cover	27085		1
84*1	Bearing 51106	27086	51106	1

Page 3

Parts List for EB330DSC (2075)

09/09/2016

PARTS LIST			P3/5	
MODEL NO. EB330DSC				
N O	DESCRIPTION	BOM	SPEC	QTY
85	Vise Handle	32061		1
86	Vise Handle Fixed Board	30086		1
86*1	CAPscrew	XCCMWS6820	CAP8*20	3
87	Spring	32033		1
89	Leadscrew	30089		1
90	Vise Handle Set	30090		1
91	Vise Handle Rod			1
91*1	Bearing	QX6904-2RS	6904	1
92	Leadscrew Copper	30092		1
92*1	Leadscrew Spring	30092*1		1
93	Moveable Vise Jaw Bracket	30093		1
93*1	Moveable DownVise Jaw Bracket Board	30093*1		2
93*2	Set screw			1
93*3	Screw			4
93*4	Set screw			1
94	Knob	30094	M10*190	1
95	Vise Plate	30095		1
95*1	Screw	XCM6F1020		2
96	vise cover	30096		1
96*1	Screw	XCM6F820	M8*20	6
96*2	Spring pin	XCWMWCG516	彈簧稍M5x16	2
96*3	Nut	XCM6A8	M8	6
97	Slide	32055		1
98	Left Vise	30098		1
98*1	Screw	XCM6F1040	10*40染黑	4
98*2	Screw	XCM6F1040	10*40染黑	2
98*3	Screw	XCM6F1040	10*40染黑	2
98*4	CAPscrew	XCCMWS6840	CAP 8*40	2
98*5	Washer	30098*5		4
99	Left Vise Plate	30099		1
100	Left Cutting Plate	30100		1
101	Fixed Vise Jaw Bracket	30101		1
101A	O ring	OV008	4.4*2.6	1
101*1	Screw	XCCMFS61025	CAP10.25	6
101*2	Indicator Fixed Board	30101*2		1
101*3	Screw			1
102	Moveable Vise Jaw Bracket Board	30102	16x75x430	1
102*1	Screw	XCMA825	皿頭8*25	3
102*2	Washer	XCCMWS6825	23*8*3	4
102*3	CAPscrew	XCCMWS6825	CAP 8x25	2
103	Bearing 51106	27086	51106	1
104	Nut	27113		1
104B	45degree Plate	27124G*4		1
104A	Screw	XCM6F1030		1
105*2	Nut	XCM6A10		3
105A	Base	30105A#7037		1
105B	Front door	30105B		1

PARTS LIST				P4/5
MODEL NO .EB330DSC				
NO	DESCRIPTION	BOM NO	SPEC	QTY
105C	CAP Screw	XCCMWS6825		2
105D	Washer	XCMM8233	8x23x3	3
105E	Screw	XCM6F1040		2
105F	Screw			1
105G	Set Nut			1
105H	Nut	XCM6A8	M8	1
105I	Handle	21GT15A/21GT14		1
106	Zeo Degree Fixed Board	30106	Φ25	1
106A	Handle	12060B	M8x30	1
106B	CAP Screw	XCCMWS61040		1
106C	Washer	XCMM8233	8x23x3	1
106D	CAP Screw	XCCMWS816	CAP M8*16	1
106E	Nut			1
107	Tank	30107#7037		1
108	Right Cutting Plate	30108		1
108*1	Screw	XCMA820	8x20	6
109	Vise Copper	30109	20*19	1
109*1	Vise Iron	30109*1	20*19	1
110	Knob Nut	27108		1
111	Screw 6*20	XCM6F620		1
112	Stop Braket	27107		1
113	Rod stock stop	27106		1
114	Right Vise	30114		1
115	Knob	32059*1		1
116	Plate	30116		1
116*1	Screw	XCCMWS6825		1
117	Right Vise Plate	30117		1
118	Miter Plate	30118		1
118*1	Screw			2
118*2	Oil Head	SU005	10x1.0直	1
118*3	Nut			2
118*4	Nut	XCM6A8		1
118*5	screw			1
119	Breaking Eletronic Board	30119		1
119*1	CAP Screw	XCCMWS6820		1
120	Nut	27113		1
122	Anti-Chip Cover	27037		1
123	Bushing	27111		1
124	Bearing 32006	QX32006		2
125	cylinder support	30125		1
125A	Spring holder	12080		1
125B	Spring support	21118G		1
125*3	Washer	XCMM8233	墊片8*23*3	1
125*1	Screw	XCCMWS6825	CAP 8*25	1
125*2	Screw	XCCMWS1065	CAP 10x65	1
125*4	Pin	XCWMWCG630	彈簧削6*30	2
125*5	Nut			1

PARTS LIST			P5/5	
MODEL NO . EB330DSC				
NO	DESCRIPTION	BOM NO	SPEC	QTY
125*6	Screw	XCCM1S61230		1
126	Clinder	30126		1
127	Oil house suppot plate	30127		1
127*1	screw	XCM6F825		1
128	Eletronic control suppote	30128#7037		1
128*1	screw			4
128*2	CAPScrew	XCCMFS61030		2
129	Swivel table	30129		1
129*1	Angle stick			1
130	Main shaft	30130		1
131	Bearing 32006	QX32006	32006	1
133	Switch cover	285200#7035		1
132	Switch Base	285200*1#7035		1
134	PUMP	1Q013		1
134A	screw			4
134B	L-copper	27136*1G		1
136	Tank	30136		1
137	House	30137		1
137A	Tube Bundle			1
138A	Front door support frame	30138A		1
138B	Back Suppot Plate	30138B		1
138C	Right Support Plate	30138C		1
138D	Left Suppot Plate	30138D		1
138E	Down Plate	30138E		1
T02	screw		M6*15	4
T02-1	Washer		M6	2
T03	screw		M10*25	4
T04	Washer		M10X27X3	4
T05	screw		5/16x1/2	8
T06	Nut		Nut 5/16	8
200	Switch Set			1
201	Speed Switch			1
202	Main switch			1
203	3 Position Button			1
204	Emergency switch			1
208	Fuse and Bridge (2A)			1
209	Fuse			1
210	Switch Cover			1
211	Screw			1
212	Terminal Block			1
218.220.222	Wire for cooling pump and motor			1
215	Plug			1
216	Fuse and Bridge (6A)			1
217	Contactor (Saw Motor High Speed) / 24V			1
219	Feed EL.Valve			1
223	Approoch EL.Valve			1
225	Start Switch			1
73	Cable Protector			1







