



AP-3

3 TONNE - ARBOR PRESS

BASE DIMENSIONS

4 - POSITION ANVIL



NOTE:
Use High tensile bolts, flat washers
and lock nuts (Not supplied)

All dimensions are in millimetres (mm)