


MeasumaX

MX-600 Series - LINEAR SCALES



L_0 = Effective measuring length of scale